

# eLINK

## user manual



# elebia®

smart lifting solutions



## Table of Contents

<b>4</b>	Safety recommendations
<b>5</b>	Intrusion Prevention
<b>6</b>	Description
<b>8</b>	Specifications
<b>10</b>	Regulatory Standards
<b>10</b>	FCC and IC
<b>11</b>	Installation
<b>13</b>	Wifi Connection and log in
<b>18</b>	Set up
<b>21</b>	Wiring Examples
<b>24</b>	Serial Port Communication
<b>31</b>	Conformity Declaration & Manufacturer's Certificate
<b>32</b>	Warranty
<b>33</b>	Annex

## Safety recommendations

This is the user manual of the eLink. Before using the eLink, users must read and understand this user manual, as well as the Elebia automatic hook user manual.

Failure to review and utilize recommended applications, operation and maintenance instructions may result in serious injury to the operator and others.

As the manufacturer has no direct control over the operation of the eLink or the elebia® auto hook, the safe handling of the equipment is therefore the responsibility of the user and of the operating personnel.

It is the sole responsibility of the operator to ensure the correct manipulation and handling of any load while using any of the Elebia products. Automated processes in any lifting operation, whether attaching and/or releasing load, or other, must always be submitted to visual inspection of the operator. Elebia designs and produces automated lifting solutions which enhance safety and productivity but can never replace the responsible and provident handling of all lifting processes.

In the event of breakdown or malfunction, withdraw the device and consult the technical service.

Use this QR code to access our helpdesk.  
There, you'll find user manuals, Q&A.  
You can also open a ticket if you need support.



## Intrusion Prevention

(Cloud version only)

The eLink, in its cloud version, can only be controlled through its incorporated web application. Under no circumstances does it allow an external connection to take remote control. Instructions from the cloud application are accessed by the eLink and are never imposed. Local action will always prevail, especially in terms of cybersecurity and IT security.

External communication is facilitated through a pair of embedded keys and a unique identification token, which are integrated into the eLink during software installation.

These measures are implemented deliberately to ensure that only those actions previously defined by Elebia can be executed on the eLink.

## Description

The eLINK is a central data acquisition and control system which allows control of the Elebia lifting hooks, through a web application. The eLINK's in/out capabilities allow crane automation using the hook's sensor data. All in a quick, flexible and simple way. It can be used to increase productivity while enhancing safety.



**Monitoring:** hook status can be monitored through the WebApp.



**Data Logger:** the eLink itself generates a Log file with all the events that are carried out while the eLink is operating, saving each event with date and timestamp thanks to the Real Time Clock that the device carries.



**Data access:** the log file can be accessed through the WebApp.



**Gateway:** eLink allows communication between the hooks, the crane, the remote controls, PLC, computers and other devices.



**Automation:** logical rules can be defined in order to perform different actions using hook status and sensor values.



**Remote Maintenance:** Elebia service team can perform preventive and remote maintenance and support using eLink data.



**Over the Air Updates:** updates, bug fixes and new features can be delivered by OTA.


### The eLINK is connected with:

1. The user: eLINK serves a WebApp and users can use smartphone, tablet or PC to connect using Wi-Fi. This allows to:
  - a. Hook control:
    - Open / close hooks, either individually or in groups.
    - Set up hook parameters.
    - Monitor hook status (open/closed, battery level, sensors, weight lifted,...).
  - b. eLink control:
    - Add / remove hooks.
    - Manage users / profiles.
    - Setup Wired Inputs/ Outputs.
    - Setup radio communication parameters.
    - Define output state using logical functions. Functions can use hook status data as well as other inputs.
2. The crane: through 8 dry contact inputs and 4 relay contact for the outputs. Optional coms: CAN Bus, RS232, RS485, RJ45, Profinet
3. The lifting hooks: through radio communication.
4. Others: PLC's, laser sensors, lights, buzzers, screens,...



Specifications

mm./in.  
1,25Kg/ 2,76lb



Swivel Dipole Antenna Specifications

Frequency	902 to 928 MHz
Nominal Impedance	50 Ohms
VSWR	2.0 Max. in Band
Gain	3.0 dBi
Polarization	Vertical
Power	1W max.

FC K CE ARIB



## eLINK Specifications

Single-Board Computer	Cortex-A17 Quad-core SoC*
Radio Frequency Communication	868.95 / 904 / 917.5 / 924.1 MHz
CANbus	1 (optional)
Inputs	8 dry contacty
Outputs	4 relay contact. Max 1A
4G Module	Optional
Real Time Clock (RTC)	Yes
Internal Storage Memory	32GB
Battery Button for RTC	CR2032
Input Source	110 / 230V AC (optional 48V CC or 24V CC)
Power consumption	11,5W (Standby)
Wi-fi	802.11 b/g/n/c double band (2.4 & 5 GHz)
Bluetooth	4.2
IP Code	IP65
Temperature Range	-20°C to 60°C
RF Antenna	862 to 930 MHz / 50 Ohms

## Regulatory Standards

- Directive on machine safety (D89/37/EEC).
- UNE-EN 1050
- UNE-EN ISO 12100-1
- UNE-EN ISO 12100-2
- UNE-EN 61000-6-4
- UNE-EN 61000-6-2
- UNE-EN 1677
- EN 10204 3.1.B
- Assurance of production quality in accordance with ISO 9001.
- Each mechanism is delivered with the CE stamp and a declaration of CE conformity.
- D89/391/EEC
- D89/654/EEC
- D89/655/EEC
- D89/656/EEC
- D92/58/EEC

## FCC and IC

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be colocated or operating in conjunction with any other antenna or transmitter, except in accordance with FCC multi-transmitter product procedures.

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna; Increase the separation between the equipment and receiver.

## Installation

### 1. Select the installation spot:

- eLink needs to be within the radio communication range of the hooks to be controlled (<100m).
- It is to be installed near to the crane control panel, with which we can directly make the appropriate wired connections of the crane elements that we want to control.
- Select a spot where the eLink is not covered by metal, as this would limit or even disable radio and Wi-Fi communications. If need to be in a metal box, both antennas must then be mounted out of the metal enclosure (you will need SMA extenders to do so).
- eLink generates a Wi-Fi so users can connect in order to manage all its features. Users will need to be within the Wi-Fi range.
- A reserved surface of 350x300mm is needed to mount the eLink.

### 2. Wall mount:

- eLink must be secured to a flat surface, using 4 screws and the template included in the box, as an option a DIN rail support.

### 3. Power supply:

- Plug the eLink into a wall socket (110 / 230V AC).
- Optional 48V CC or 24V CC power supply are available as an option.


### 4. Connections:

- eLink has 8 dry contact inputs and 4 Relay Contact outputs, as well as serial bus options (RS232 /RS-485), Ethernet (RJ45), CAN Bus and Profinet. (optional).
- Depending on your application you should make the desired electrical connections. Read 'Examples' section for more information.



*eLink installation process*

## Mounting and Fixation Guide



1. Open the box and remove the lid.
2. Position the eLink device in its designated mounting location.
3. Secure it by inserting bolts or screws through the mounting holes at the indicated points. (This step does not apply if using the DIN rail mounting option.)

*In the annex, you will find a full-scale mounting template to assist with proper installation.*

## Wifi Connection and Log in

eLink Wi-Fi can be configured as a Hotspot or connected to a LAN.



**IP address:** <http://10.42.0.1:3000>

**Wifi ID:** Elebia\_eLink\_SNXXXXX

**Password:** eLinkConXXXXX

For your convenience, there is a sticker with the login instructions located on one side of the eLink.

1. Use your smartphone, tablet or PC to connect to '**Elebia\_eLink\_SNxxxxx**' Wi-Fi and type the Wi-Fi password '**eLinkConXXXXX**' where XXXXX is the serial number of your eLink. If you don't find the Wi-Fi named '**Elebia\_eLink\_SNxxxxx**', make sure you are within the eLink Wi-Fi range and eLink is connected to a power source, and the 'Ready' and 'Wi-Fi' led status are 'on'.

2. Connect to the eLink IP by one of the following options:
  - a. Open a browser on your device and type IP found on the eLink sticker.
  - b. Use this QR code.



This QR code can also be found in the eLink. A second copy of the sticker is delivered in the box. We advise you to place it in a spot where users might have easy access to.

3. Save the IP in your 'favorites' as '**Elebia eLink**'
4. Login with username '**admin@elink.io**' and password '**password**'. For security reasons, change this password once you are logged in (go to Configuration>Users).

A screenshot of the elebia login interface. It features the elebia logo at the top, followed by the tagline "smart lifting solutions". Below this are two input fields: "Email" and "Password". The "Password" field has a small eye icon to its right. At the bottom is a blue "Sign in" button.

elebia®  
smart lifting solutions

Email

Password

Sign in

**Local area network (LAN) connection.**

**IP address:** <http://10.42.0.1:3000>

**Wifi ID:** Elebia\_eLink\_SNXXXXXX

**Password:** eLinkConXXXXXX

By default the eLink is set to hotspot, but it can be connected to a LAN using WiFi (Configuration>connection>hotspot/WiFi ).

Connection

WIFI ☒ HOTSPOT

Connection Name: Elebia\_eLink\_SN00001

Connection Type: hotspot

IP10.42.0.1

Other Networks

SSID

Wifi SSID

Password

Wifi password

Connect

Close

The first time you switch to LAN, you will have to type your facilities LAN SSID and password using the 'Other Networks' section placed at the bottom of the WIFI section, and press the Connect button to go ahead with the change.

If your credentials are valid, eLink will connect to the LAN.

Connection

WIFI ☐ HOTSPOT

Connection Name: Elebia-Test

Connection Type: wifi

IP192.168.50.164

Load Available Wifi

SSID

PASSWORD

Other Networks

SSID

Wifi SSID

Password

Wifi password

Close



Network

Connection Name:

WIFI ☐ HOTSPOT ☒

Elebia

Connection Type:

wifi

IP

192.168.47.219

⌂ Load Available Wifi

SSID	PASSWORD		
ELEBIA-GUEST	Wifi password		Connect
ELEBIA-TEST	Wifi password		Connect
ELEBIA-GUEST	Wifi password		Connect

Close

When you switch from hotspot to LAN, the eLink will indicate the new IP address you'll have to connect to get access to the App. Save the IP in your 'favorites' as '**Elebia eLink (LAN)**'.

ATTENTION: Please note that you will need to contact your IT department to assign a fixed IP address to the eLink device. Without a fixed IP address, the device will receive a different IP address with each new connection.

In case WiFi LAN connection is lost, or if the eLink is rebooted, it will switch to a hotspot. Then you'll need to connect to the IP saved in your favorites as '**Elebia in hotspot**'

## Set up

### Hook setup:


Upon customer request, the eLink will be delivered with the hooks already registered. The main screen will display the following:



- |                            |                         |
|----------------------------|-------------------------|
| 1 Hook status              | 8 Tare                  |
| 2 Battery level            | 9 Weight capture        |
| 3 Radio strenght           | 10 Angle info           |
| 4 Manual open/close button | 11 Hook settings        |
| 5 Temperature              | 12 Remove Hook          |
| 6 Weight info              | 13 Relay/ Output status |
| 7 Magnet sensor            | 14 Input Status         |

**Registering new hooks:** If you need to register hooks, it is an easy and quick process.

1. Logg In as Admin.
2. Click the button on the top right area, **Add hooks**.
3. Type the serial number and give it a name.



### Setup Users:

The eLink uses profiles to determine what features can be accessed. That's why It is very important to assign the right profile to each user.

There are 4 profiles or kind of users:

- **User:** those who will be operating the autohooks. This profile only allows hook operation and can't modify the settings.
- **Admin:** those (within the company) in charge of managing the hooks and the eLink. This profile allows you to adjust the basic settings, add/remove hooks.... **It is not for daily operation of the hook.**
- **Service:** this profile is for Elebia technical service only.
- **Factory:** this profile is for Elebia personel only.

'User ' is the lower level and 'Factory' is the higher. The higher the profile, the more options are available in the menus.

All the profiles need a password to login. Each user can modify its own password. Admin can create, delete and modify User passwords. (Configuration>Users)

		User Level			
Features		User	Admin	Service	Factory
App login	Hotspot	x	x	x	x
	LAN	x	x	x	x
	Cloud		*	x	x
hook	info center	x	x	x	x
	tare	x	x	x	x
	net/gross	x	x	x	x
	name		x	x	x
	serial		x	x	x
	disable		x	x	x
	delete		x	x	x
	add		x	x	x
	settings			x	x
	Open		x	x	x
	Close		x	x	x
eLink	Outputs (Relays)			x	x
	Inputs (Wired)			x	x
	Inputs (Radio)			x	x
	Radio			x	x
	Users		x	x	x
	Update environment				x
	Update		x	x	x
	Other settings			x	x
	Network		x	x	x
	Event log		x	x	x


*\*This table has the default values. It can be customized for every eLink.*

## Wiring Examples

Here we share some wiring examples for different uses of the eLink. If you need support or have any doubts, feel free to contact us (open a ticket in [helpdesk](#)).

**Example1: Use the existing crane remote control to open/close the elebia automatic hooks.**


- Customer wants to control one elebia hook with the existing crane remote control.
- Crane remote control has 1 available button.



Once wires are connected, proceed with the set up:

- 1.Open the web app.
- 2.Log in.
- 3.Go to eLink configuration .
- 4.go to the Inputs & outputs section and select INPUTS (Wired).
- 5.Select the input number where the wires from the crane radio receiver have been connected.
- 6.Select the hook you want to control.
- 7.Select 'toggle' from the drop down menu.

If customer has 2 available buttons and wants 2 separated orders for open and close, it can be done in the same manner, but using 2 wired inputs and instead of 'toggle', select 'open' and 'close' on the drop down menu.




In this manner, up to 8 hooks can be controlled with toggle function, and 4 hooks on the open/close function.

**Example 2: Interlock. Disable vertical movement of the hoist while hook is in transition (hook not fully open or fully closed).**

- Crane should never lift until the hook is fully closed or fully opened.
- Customer wants to disable vertical movement of the crane while hook is in transition (hook not fully open or fully closed).
- By doing so, will prevent accidents and will increase lifespan of the crane and the hook.


Once wires are connected, proceed with the set up:

1. Open the web app.
2. Log in.
3. Go to eLink settings.
4. Go to OUTPUTS.
5. Select the relay output number where the wires from the crane control have been connected.
6. Type the formula:
  - **`[(hook1.state!=open)&&(hook1.state!=closed)&&(hook1.state!=disabled)]`.**



**Example 3: Multiple Interlock. Disable vertical movement of the hoist/s while hooks are not fully open (both) or fully closed (both).**

- In a multi-point lift, crane should never try to lift a load if some hooks are opened and some are closed or some are in transition.
- Customer wants to disable vertical movement of the crane while hooks are not fully open or fully closed (simultaneously).
- By doing so, will prevent accidents and will increase lifespan of the crane, the beam, the hook and the goods being lifted.



Once wires are connected, proceed with the set up:

1. Open the web app.
2. Log in.
3. Go to eLink Configuration.
4. Go to the Inputs & outputs section and select OUTPUTS (Relays).
5. Select the output number where the wires from the crane control have been connected.
6. Type the formula:
  - **((hook1.state==open)&&[hook1.state!=disabled]&&[hook2.state==open]&&[hook2.state!=disabled]))|((hook1.state==closed)&&[hook1.state!=disabled]&&[hook2.state==closed]&&[hook2.state!=disabled])**
7. Select the output state, which can be Enabled or Disabled. Enabled in this case.

eLink Configuration >

**Inputs & outputs** ^

RS-232 v

**Outputs (Relays)** ^

Outputs Enable: ☒

OUTPUT 1   OUTPUT 2   OUTPUT 3   OUTPUT 4

---

**Note:** Use this words into your formula opening hook#.state: **open / closed / middle / offline / disabled**, hook#.ring: **detected / notdetected**, hook#.weight: **kg**, input#: **active / inactive**

Logical Condition

```
((hook1.state==open)&&[hook1.state!=disabled]&&[hook2.state==open]&&[hook2.state!=disabled]))|((hook1.state==closed)&&[hook1.state!=disabled]&&[hook2.state==closed]&&[hook2.state!=disabled])
```

**Resume Relay 1:** ((hook1.state==open)&&[hook1.state!=disabled]&&[hook2.state==open]&&[hook2.state!=disabled]))|((hook1.state==closed)&&[hook1.state!=disabled]&&[hook2.state==closed]&&[hook2.state!=disabled])

Output State:

Enable v

Output Name:

No middle

**Save**

## Serial Port Communication

Only For eLink units mounting the serial port connector option.

### Commands list

Number	Description	Request frame format	Primary Successful Response
2	Commands List	\$002\r\n	#002,OK\r\n
39	Get Hook Serial Number	\$039,n\r\n	#039,n,sssss,OK\r\n
48	Get Hook State	\$048,n\r\n	#048,n,sssss,OK\r\n
120	Open Hook	\$120,n\r\n	#120,n,OK\r\n
121	Close Hook	\$121,n\r\n	#121,n,OK\r\n
122	Toggle Hook	\$122,n\r\n	#122,n,OK\r\n
125	Get Current Weight	\$125,n\r\n	#125,n,wwwww,OK\r\n
126	Set Tare	\$126,n\r\n	#126,n,ttttt,OK\r\n
127	Set User Zero	\$127,n\r\n	#127,n,OK\r\n

### Parameters list

Code	Name	Description
n	[hook number]	One or two ascii digit, indicating the hook position; can be from 0 to 23.
sssss	[serial number]	Five digit serial number of the hook in ascii forma
sssss	[state code]	Six numbers in ascii format:
		1 Ring indicator, 0 for no presence, 1 for ring in position
		2 Hook position, 0 for middle position, 1 for closed position, 2 for open position, 3 hook offline, 4 hook disabled
		3 battery level from 0 to 9
		4 RSSI level
		5 reserved
		6 reserved
wwwww	[weight]	Six digit decimal number in ascii format representing the weight in Kg
ttttt	[Tare]	Six digit decimal number in ascii format representing the tare in Kg




## Usage

Connecting a device through RS232 / RS485 eLink's port allows sending the specified commands and parameters to the eLink.

## Connection using Docklight program


This is intended to simulate a device to communicate with the eLink. <https://docklight.de/>

## Settings



Once settings are configured communication must be started.

Commands send/receive



Commands send/receive examples

Marked on green send commands from the external device (TX) and on red responses from the eLink.

Commands examples (Send TX - Receive RX)	
Commands list	
19/6/2024 11:58:26.432	[TX] - \$002<CR><LF>
19/6/2024 11:58:26.446	[RX] - #002,OK<CR><LF>
Get hook serial number	
19/6/2024 11:58:29.161	[TX] - \$039,1<CR><LF>
19/6/2024 11:58:29.197	[RX] - #039,1,02064,OK<CR><LF>

Commands examples (Send TX - Receive RX)	
<b>Get Hook State</b>	
19/6/2024 11:58:31.714	[TX] - \$048,1<CR><LF>
19/6/2024 11:58:31.757	[RX] - #048,1,017700,OK<CR><LF>
19/6/2024 11:59:41.345	[RX] - #048,1,007800,OK<CR><LF>
19/6/2024 11:55:50.678	[RX] - #048,1,027800,OK<CR><LF>
<b>Open Hook</b>	
19/6/2024 11:58:34.009	[TX] - \$120,1<CR><LF>
19/6/2024 11:58:34.124	[RX] - #120,1,OK<CR><LF>
<b>Close Hook</b>	
19/6/2024 11:58:36.413	[TX] - \$121,1<CR><LF>
19/6/2024 11:58:36.860	[RX] - #121,1,OK<CR><LF>
<b>Toggle Hook</b>	
19/6/2024 11:58:39.530	[TX] - \$122,1<CR><LF>
19/6/2024 11:58:39.563	[RX] - #122,1,OK<CR><LF>
<b>Get Current Weight</b>	
19/6/2024 11:58:41.830	[TX] - \$125,1<CR><LF>
19/6/2024 11:58:41.867	[RX] - #125,1,000400,OK<CR><LF>
<b>Set Tare</b>	
19/6/2024 11:58:43.862	[TX] - \$126,1<CR><LF>
19/6/2024 11:58:43.915	[RX] - #126,1,OK<CR><LF>
<b>Set User Zero</b>	
19/6/2024 11:58:45.865	[TX] - \$127,1<CR><LF>
19/6/2024 11:58:45.882	[RX] - #127,1,OK<CR><LF>

USB to RS232/485 converter

eLink incorporates the Waveshare USB to RS232/485 converter




Indicator	Description
① 120Ω resistor switch	enable or disable RS485 terminal 120Ω resistor
② RS232/485 switch	for switching RS232 for RS485 communication
③ RX_ B:	RS232 receive data / RS485 differential signal negative B-
④ TX_ A:	RS232 transmit data / RS485 differential signal positive A+
⑤ GND:	RS232/485 signal ground


## Wiring connectivity

When connecting the eLink unit to the RS232 device, please check the wiring connectivity.

Simple null modem cable for RS232




Simple straight through for RS485



eLink RS232 setup

Activation of RS232 communication



## Conformity Declaration and Manufacturer's Certificate

ELEBIA AUTOHOOKS, S.L.U., with registered office at Plaça Pere Llauger Prim, naus 10-11, Polígon Industrial Can Misser, 08360, Canet de Mar, (Barcelona), Spain, Tax Identification Certificate B65770265, and ISO 9001 Certificate No. 9000041

### DECLARES:

Under its sole responsibility, that the following model eLink remote control for the elebia® automatic hook system, with serial number \_\_\_\_\_, complies with the EC Machinery Directive 2006/42/EC of the European Parliament and of the Council, of 22 June 1998, on the approximation of the laws of the Member States relating to machinery, and 2004/108/EC, on the approximation of the laws of the Member States relating to electromagnetic compatibility, and has been manufactured in accordance with the following harmonized standards:

EN 300 220 TELECOMMUNICATIONS

EN 301 489 ELECTROMAGNETIC COMPATIBILITY EN 60730 LOW VOLTAGE

As stipulated by EC Machinery Directive:

- CE symbol fixed to the elink.
- Technical documentation filed in manufacturer's site.

Authorised signatory:

Oscar Fillol Vidal

CEO of ELEBIA AUTOHOOKS



Barcelona, June 2025

## Warranty


The guarantee for elebia® eLink is for 2 years and covers parts and labor for the use envisaged and recommended in the system's manual of use. Maintenance operations, and the materials and labor involved therein, are exempt from guarantee.

Distributor / Service:

Date:



## Annex



# elebia®

smart lifting solutions



Plaça Pere Llauger Prim, Naus 10-11  
Polígon Industrial Can Misser  
08360 Canet de Mar (Barcelona) Spain  
Tel. (+34) 93 543 4706

**[www.elebia.com](http://www.elebia.com)**  
**[info@elebia.com](mailto:info@elebia.com)**